



gourmet cooks kitchen

assembly instructions

145756 0417
Early Learning Centre®
Watford WD24 6SH England.

Customer Service Department
0371 231 3513

contents

Equipment Needed: 1 x cross head screwdriver
1 x flat head screw driver

1 x1	2 x1	3 x1	4 x1
5 x1	6 x1	7 x1	8 x1
9 x1	10 x1	11 x1	12 x1
13 x1	14 x1	15 x1	16 x1
17 x1	18 x1	19 x1	20 x1
21 x1 327 x 295MM	22 x1	23 x1	24 x1
25 x1 275 x 285MM	26 x1	27 x1	28 x1

page 1

contents

29 x1	30 x2	31 x1	32 x1	33 x1	34 x1
35 x1	36 x2	37 x1	38 x1	39 x2	40 x6
41 x1	42 x5 Nylon Strip	43 x5	44 x45 3 x 8 x 5MM	45 x13 3,5 x 21MM	46 x2
47 x8	48 x8	49 x8	50 x44 3,2 x 27MM	51 x10	52 x10
53 x4 3 x 19	54 x18 3,5x12	55 x4	56 x1		

assembly

A	B	C
D	E	F
G		

page 2

assembly

