


mothercare



4 way
vibrating carrier

user guide

IMPORTANT! KEEP FOR
FUTURE REFERENCE

Important - Read these instructions carefully and retain for future reference

The 4 way carrier offers three comfortable ways of moving around, hands free, whilst keeping baby close. It features a nursing position and a soothing vibration unit.

- i) Inward facing - the traditional way to carry baby (from birth)
- ii) Forward facing - the carrier can be used forward facing when your baby can support their own head (approximately 3 months +)
- iii) Back carrier - for babies from approximately 6 months.
- iv) Nursing position

Important

The carrier is suitable:

From birth to 12kg (approximately 18 months)

Forward facing from approximately 3 months

Back carrying from approximately 6 months

Only use the baby carrier when standing, walking or sitting.
Never use for sports activities.

Before putting your baby in the carrier, practice putting the carrier on and taking it off to ensure you are familiar with all procedures.

Always check all the buckles and fastenings are securely closed and the straps correctly fitted and adjusted before using the carrier.

Be aware that your child will suffer from the effects of the weather before you.

Your balance may be affected by your own and your child's movement.
Take great care when leaning forward.


Take frequent breaks as you and your child can become tired.

1




Pass the padded lumbar support around your waist and fasten the buckle behind you. Adjust the strap until you are comfortable.

2



Pass the padded shoulder straps over your head, crossing behind your back, and buckle into place at both sides of the carrier. Adjust the webbing straps to ensure the correct fit.


3



Sitting down, release the fasteners and lay the carrier on your knees. Place baby into the carrier.


Important. Always check all the buckles and fastenings are securely closed and the straps correctly fitted and adjusted before using the carrier.

4




Remaining seated, attach the fasteners and buckles on both sides of the carrier.

5




Adjust the straps so the back support fits comfortably and securely against baby. Baby should be upright and their weight distributed evenly in the carrier. Attach the dribble bib if required.

6



If required, the adjustable head hugger can be attached to the fasteners on the inside of the head support.

7



Tuck the ends of waist strap webbing into the tab(s) to keep tidy.

3


Important. Always check all the buckles and fastenings are securely closed and the straps correctly fitted and adjusted before using the carrier.

1



Pass the padded lumbar support around your waist and fasten the buckle behind you. Adjust the strap until you are comfortable.


2



Pass the padded shoulder straps over your head, crossing behind your back, and buckle into place at both sides of the carrier.

Adjust the webbing straps to ensure the correct fit.

3



Sitting down, lay the carrier on your knees.


Place baby into the carrier.

Fold the padded head support down.

Attach the fasteners and buckles on both sides of the carrier.


Important. Always check all the buckles and fastenings are securely closed and the straps correctly fitted and adjusted before using the carrier.

4




Remaining seated, adjust the straps so the folded back support fits comfortably and securely against baby.

5



Adjust the shoulder straps so baby's weight is distributed evenly in the carrier.

6




Tuck the ends of waist strap webbing into the tab(s) to keep tidy.

Important. Always check all the buckles and fastenings are securely closed and the straps correctly fitted and adjusted before using the carrier.


You will need assistance to put the carrier and baby onto your back.

1




The crossover strap holder can be removed if not required.

2




Place the carrier on a flat surface. Place baby into the carrier and attach the fastenings and buckles.

3



Have someone hold baby at your back. Pass the shoulder straps over your shoulders, crossing at the front, and fasten the side buckles. Adjust the straps as required. Baby should be upright and their weight distributed evenly in the carrier.


4



Fasten the waist belt around your waist and fasten the buckle in front of you. Adjust the strap until you are comfortable.


Important. Always check all the buckles and fastenings are securely closed and the straps correctly fitted and adjusted before using the carrier.

1




Before nursing, adjust the carrier so baby is in the inward facing position, then release the upper clip on the side you wish to feed.

2




Release the flaps on both sides and fold the head support down.

3




Support baby with one hand and release the lower clip on the side you wish to feed.

4




Tuck the flap between yourself and the carrier, so the fastening material does not scratch baby.

5



Position baby for feeding.

1




The vibration unit should be fitted with batteries before use (refer to section 7, battery installation).

2




Switch on the vibration unit by sliding the switch to "on"

3



Put the vibration unit into the front pocket of the carrier


4



If you do not want to use vibration, switch off by sliding the switch to "off"


Philips head screwdriver and 2 X "AAA" (1.5V) batteries required (not included)
Only the recommended batteries are to be used.
Do not use rechargeable batteries.

1



Open the battery cover with a small headed Philips screwdriver.

2




Install batteries as indicated, making sure the batteries are installed with the correct polarity.

Do not short circuit the battery terminals.



3



Close the battery cover with the screwdriver.

4



Read battery safety guidelines carefully before use.

- Remove the dribble bib and wash separately.




- Buckle all straps before laundering.
- Machine wash separately.
- DO NOT USE CHLORINE BLEACH.
- Tumble dry 10-15 minutes using low heat.
- Remove immediately.
- Do not dry clean.
- Do not iron.
- Remove vibration unit before washing.



- This baby carrier is designed for babies up to 12kg. (Approx 18 months)
- The straps, buckles and their attachments should be inspected regularly for signs of wear or damage.
- Never use as a child restraint in a vehicle. Always use an approved vehicle child restraint.


Your child's safety is your responsibility.

ALWAYS



Take care to fit your batteries correctly, observing the plus and minus marks on the battery and appliance.

ALWAYS



Replace the whole set of batteries at one time, taking care not to mix old and new batteries or batteries of different types.

ALWAYS



Store unused batteries in their packaging and away from metal objects which may cause a short circuit.

ALWAYS




Remove dead batteries from equipment and all batteries from equipment you know you are not going to use for a long time. Batteries may leak.

NEVER




Never dispose of batteries in fire as this may cause them to explode. Please put dead batteries in with the normal household waste.

NEVER



Never attempt to recharge ordinary batteries, either in a charger or by applying heat to them. There are special rechargeable batteries which are marked as such.

ALWAYS



Make sure battery compartments are secure.