



framed back carrier


user guide

IMPORTANT! KEEP FOR
FUTURE REFERENCE

The framed back carrier is suitable for children who can sit up unaided (around 6 months) to 16 kg in weight, and is suitable for leisure activities such as walking, but not for sports such as running or cycling.

The carrier features a large zipped pocket for baby accessories such as nappies, plus a smaller pocket.

diagram



description


upper frame with seat

lower frame (linked by shoulder straps)

bag

assembling the back carrier


1



The back carrier frame is supplied in two parts.


To assemble, insert the ends of the frame into the black plastic hinges, ensuring the silver buttons locate in the holes.

2




The 2 straps should be attached to the frame as shown.

3



The bag is attached by four straps and buttons. Two fix above the hinges and two fix on the back legs as shown.


4



Pull out the hinged stand.
Place the back carrier on a clean, level surface.

harness


1



TO ATTACH THE HARNESS

Insert the fastener securely into the clasp.
Adjust each strap length with the buckles 'A'.

2




TO UNDO THE HARNESS

Press the fastener prongs and pull apart the harness.
Your child should always be securely harnessed, and should never be left unattended even for short periods.


placing your child in the carrier

3



Lift the shoulder straps out over the backrest and place your child in the back carrier, gently guiding their legs through the side openings.


4



Bring the safety harness over your child's head and fasten. Adjust the shoulder straps to suit your child's size.

putting the carrier on your back

5




You are recommended to use the assistance of another adult when putting the back carrier on.

Place the carrier on your back, slide each of your arms into and through the shoulder straps.

Make sure the carrier is sitting comfortably.


Pull the two ends of the chest strap together and secure the buckle.

6




Pull the two ends of the waist strap to the front and secure the buckle. Adjust the belt if necessary. It should fit securely but not too tightly.

7



Adjust the fit of the shoulder straps by pulling the loose ends of the straps. The straps should fit securely but not too tightly.

8



Make sure that all fingers and toes are clear of the stand before pulling it in against the frame.


removing the back carrier from your back

1



Push the stand away from the frame.

2



Release the waist strap.

3



Release the chest strap.

Carefully lift the back carrier off and place on the floor.
Avoid swinging the backpack around too abruptly.

- To clean the seat, wipe the fabric with a damp cloth using warm water and mild detergent only. Allow to air dry.
- To clean the frame, wipe the metal surface with a damp cloth using warm water only. Dry completely using a soft cloth.
- To dry the carrier, always open out fully to allow air to circulate all around the fabric.
- Clean the surfaces of the carrier only. Do not immerse in water.
- Do not use strong detergents, abrasive or ammonia based cleaners.
- Regularly inspect the carrier for wear and tear and discontinue if any part damaged or broken.

- **WARNING** - Do not leave the child unattended in this carrier!
- **WARNING** - Do not use until the child can sit unaided.
- **WARNING** - When the child is in the carrier, it could be in a position higher than the carer. Care should therefore be taken to be aware of hazards e.g. door frames, low branches of trees etc.
- **WARNING** - When using the carrier, the carer shall be aware of the following:
 - the carers balance may be adversely affected due to movement of the child and also the carer;
 - the carer will need to take great care when bending or leaning forwards;
 - the carrier is suitable for use when undertaking leisure activities but not for sports activities;
 - care should be taken when putting on or removing the carrier.
- Ensure your child wears the harness, correctly fitted and adjusted at all times.
- The child in the carrier can become tired quickly, so frequent breaks are recommended.
- Be aware that the child in the carrier may suffer from the effects of weather and temperature before you do.
- Care should be taken to avoid injury to the child's feet when the carrier is on or near the floor. Note that the carrier will not stand unaided.
- Do not use replacement parts or accessories other than those approved by Mothercare as they may make the carrier unsafe.
- Ensure children are clear of moving parts before making adjustments.
- Overloading, incorrect folding and the use of non-approved accessories may damage or break this carrier.