


mothercare



reclining booster seat

user guide

Important! Keep for
future reference


This booster seat allows your child to sit with you whenever using a table, by securing the booster on a suitable chair*. For added comfort, the booster can be reclined to any of three positions.

Suitable for children who can sit unaided (around six to nine months) to around 4 years.

* Refer to section 6, safety notes for information on suitable types of chairs.

Tools required: medium Phillips screwdriver

diagram



description

backrest


booster with harness

removable tray


securing strap

2 short screws (12 mm)

2 long screws (22 mm)




1. Locate both sides of the backrest under the ends of the armrest.
2. Press the top of the backrest in the direction shown.



At the back of the seat, fit the two short screws where shown, using a medium size Phillips screwdriver.

Note: Screws not shown to scale.




At the back of the seat, fit the two long screws where shown.

Note: Screws not shown to scale.


Tip. Use a piece of Blu-Tack or plasticine to hold the screw on the screwdriver when fixing these screws.

4



Push the ends of the shoulder straps through the backrest slots (1), and open the webbing out (2) so it cannot pull back through the slots.

5




1. Push the ends of the securing strap through the two slots in the base of the seat and open out the webbing so it cannot pull back through the slots (just as on the shoulder straps).

2. Position the booster on the chair*, wrap the securing strap underneath, and fasten the buckle.

Tighten the securing strap by pulling on the end of the strap to remove any slack.

* Refer to section 6, safety notes for information on suitable types of chairs.

6




To avoid damage to the chair or buckle, both ends of the rear securing strap are adjustable so the buckle position can be positioned away from the corners of the chair.

Tighten the securing strap by pulling on the end of the strap to remove any slack.

Always check that the booster is secure and stable before putting your child in.

harness

1




To fasten the harness

Insert both fasteners securely into the clasp.

Adjust each strap length with buckles A.

2




To release the harness

Press the fastener prongs and pull apart.

Your child should be securely harnessed at all times and should never be left unattended, even for short periods.

reclining seat

3



The seat can be reclined to any of three positions.


Squeeze the handle underneath the front of the seat upwards to release, and adjust the seat to the preferred position.

CAUTION: Ensure the child's hands and feet are clear of moving parts before making any adjustments.

Release the handle to lock and check that it has locked securely.


tray

4




Attach the tray by inserting the fixing into the armrest socket as shown.

5




Secure this side of the tray in place by rotating the knob to the locked position, indicated by a locked padlock symbol.

6




Swing the tray into place as shown below.

7



Check that the clip has engaged and that the tray is secure before use.


8



To release the tray, pull clip 1 outwards and swing the tray out, 2.

The tray can be removed by rotating the knob (refer diagram 4, page 5) to the unlocked position and lifting off.

strap removal




To remove the harness straps for washing, pinch the ends of the straps to flatten them, and pass them through the slots.

The straps can be machine washed at 40 degrees centigrade.

When re-fitting, ensure the ends open out again so they cannot accidentally pull through the slots.

- The booster can be cleaned by sponging with warm water and a mild detergent. A mild disinfectant may be used.
- Stubborn marks may be removed with a non-abrasive cream cleaner. Never clean with abrasive, ammonia based, bleach based or spirit type cleaners.
- Periodically check for damage, including internally, and discontinue use if any part is damaged or broken.



The recommended type of chair is as shown left, with four legs, a high backrest, and firm seat. If the chair has a cushioned seat, check the securing strap periodically to ensure it has not loosened.

For use on a chair whose seat dimensions are greater than those of the booster seat

Do not use the booster on a table top, stool, swivel chair, folding chair or any other type of chair that the booster cannot be firmly secured to.

- **WARNING! YOUR CHILD'S SAFETY IS YOUR RESPONSIBILITY.**
- The booster must be fully secured on the seat before placing a child inside.
- Ensure the harness is correctly fitted and adjusted at all times.
- When using the booster at a table, ensure the child cannot push against the table or another chair, and tip the booster and chair over.
- Keep away from trailing cords flexes, electric irons, ornaments and other such hazards.
- Do not use close to any source of heat.
- Never use the booster in a vehicle as a car seat.
- Do not move the booster or chair with the child inside.
- Do not use if any part is broken, damaged or missing.
- If the booster is used by someone unfamiliar with it e.g. grandparents always show them how it is used.
- Never leave your child unattended, even for the shortest time.